

BOSS™ SEATS



Installation Instructions

1. Remove the stock seat.

Remove the four bolts that hold the metal seat support to the tunnel. Pull the seat back and off of the snowmobile.

2. Loosen the gas tank shroud.

Remove the four screws and two push pins. Two of the screws are located under the hood right in front of the handlebars. The others are on the left and right side.

3. Clean the gas tank.

Thoroughly clean the gas tank with acetone or a similar solvent. Lacquer thinner works well for this.

4. Attach the seat mounting brackets.

Remove the two screws that hold the gas tank down. Insert the seat mounting brackets, and replace the screws. Tighten them down. Mark on the mounting brackets where you would like to mount the snap studs, and drill the holes. Mount the snap studs with the supplied rivets.

5. Fasten the Velcro.

Fasten the included strips of hook Velcro on the gas tank so they will match up with the loop Velcro on the bottom of the seat when you put it on. Lift the gas tank shroud and hook the gas tank loop around the neck of the gas tank. Replace the shroud and tighten the four screws and two push pins that hold it in place. Place the seat in the desired location.

6. Fasten the snaps.

Pull the seat snaps down tight and secure them to the snap studs that were just installed.

7. Clean up & ride.

Now that the seat is installed, blow it off with air or wipe with a damp cloth.

NOTE: Material has been treated with UV inhibitors, however all vinyls and fabrics last longer if kept out of the sun for long periods of time.