

BOSS™ SEATS



Installation Instructions

1. Remove the stock seat.

Remove the two bolts in the rear of the seat. Lift up and pull back on the seat. Disconnect the light plug.

2. Retrieve the taillight wires.

If you are retaining the stock taillight you must retrieve the wires from the stock seat. Once you have the wires, plug them back into the plug on the sled and fasten them down to the tunnel.

3. Clean the tunnel.

Thoroughly clean the tunnel with acetone or a similar solvent. Lacquer thinner works well.

4. Fasten the Velcro.

Fasten the included strips of hook Velcro on the tunnel so they will match up with the loop Velcro on the bottom of the seat when you put it on. Hook the gas tank loop around the neck of the gas tank, and place the seat in the desired location.

5. Fasten the front snaps.

DO THE FRONT SNAPS FIRST! Pull the snap flaps forward and down. (Pull forward to remove any wrinkles from the side panel, and then pull down to match the tunnel line.) Mark the tunnel where you would like to mount the snap studs. An easy trick to help you mark for the snaps accurately is to apply a strip of masking tape along the tunnel in the general area where the snaps will go. Then, as you pull the flaps forward and down, press the snap on the flap against the masking tape. This will leave an imprint on the tape of the exact location for drilling the holes. Drill the holes and remove the masking tape from the tunnel. Attach the snap studs using the supplied rivets, and then attach the flaps to the installed studs.

6. Fasten the rear snaps.

After you have both front snap flaps attached, then start on the rear snaps (located on the rear corners of the seat pouch). Take the mounting brackets that are included and mark the tunnel where they will be mounted, making sure to pull the seat back and tight. Attach the 3-holed edge of the brackets directly to the tunnel with the supplied rivets. Then mount the snap studs to the brackets with the remaining rivets, and fasten the snaps.

7. Clean up & ride.

Now that the seat is installed, blow it off with air or wipe with a damp cloth.

NOTE: Material has been treated with UV inhibitors, however all vinyls and fabrics last longer if kept out of the sun for long periods of time.